


ERRATA CORRIGE

Agitatori da soffitto MF-2215AS e MF-2216ASL

Come eseguire correttamente il collegamento del controller

Di seguito lo schema corretto per il collegamento del controller a parete. Esso annulla e sostituisce quello presente a pag. 4 del manuale che accompagna l'apparecchio.



Il collegamento con lo schema presente in origine sul manuale non costituisce condizione di rischio elettrico, tuttavia non consente la piena funzionalità dell'apparecchio. Ci raccomandiamo di osservare comunque tutte le prescrizioni di sicurezza riportate nel manuale, nelle pagine iniziali.


Il team tecnico

ERRATA CORRIGE

MF-2215AS / MF-2216ASL ceiling fan

How to properly connect the controller

Below is the correct diagram for connecting the controller to the wall. It cancels and replaces the one present on page. 4 of the manual accompanying the appliance.



The connection with the diagram originally present in the manual does not constitute a condition of electrical risk, but it does not allow full functionality of the appliance. In any case, we recommend that you observe all the safety instructions given in the manual, on the initial pages.

Technical team